

LifeSmart® Simply Brilliant

OUTDOOR CAMERA Model.LS179
Setting up your LifeSmart Outdoor Camera
User Guide V 1.0

PRODUCT INTRODUCTION

The LifeSmart's Outdoor Camera lets you keep tab on what is happening in the around your home via the LifeSmart App - anytime, anywhere. Simply view the live stream on your mobile device. With a large viewing angle, you can keep an eye on your house, yard or the office 24 hours a day. With sound-light alarm enabled, you may be informed if there is anyone suspicious around your house and it can scare away suspicious person. The two-way talk also enables real-time talk with people coming at your doorway.

Disposal And Recycling Information

This symbol indicates that this product and/or battery should not be disposed of with household waste. When you decide to dispose of this product and/or its battery, do so in accordance with local environmental laws and quidelines.



IN YOUR PACKAGE

- · Outdoor Camera 1 · Power Adapter 1
- · User Guide 1 · Screw Patch 1

SPECIFICATIONS

Measurements	66*66*182mm (a stand included)
Weight	375g
Color	Ivory
Resolution	1080P
Communication Protocol	WiFi
Operating humidity	5~90%RH
Operating Temperature	- 5∼ 45°C

SET UP

Your device requires a LifeSmart Smart Station and the LifeSmart App to operate. Please download the App to your smart device and set up your Smart Station before proceeding. The App is available by scanning the following QR Code or going directly to the Google Play Store or iOS App Store.

▶ Method 1

► Method 2

www.ilifesmart.com/getapp.html



SET UP

Wired Network Connection Set Up

- ① The Outdoor Camera works with a network connected cable. You can plug in your working cable to the socket of the device;
- Please make sure your Outdoor Camera is in the same network with your Smart Station.
- ① Log in LifeSmart App, click 'Menu'-'Advanced Settings'-'Add Configured Smart Device'-'Search', If you have Smart Station or click "+" button on top right corner of the home page, then click 'Add Network to Smart Station' and choose a Smart Station, wait until your Outdoor Camera is discovered, choose Outdoor Camera and click confirm to complete setup;

SET UP

Wireless Network Connection Set Up

- Log in LifeSmart App, click '+' on the top right corner of the home page, then click 'Add New Device', choose 'Outdoor Camera' and enter it's pairing page;
- ② Follow the instruction to complete pairing process.

WARRANTY DESCRIPTION

Thank you for purchasing this LifeSmart product. In order to protect your rights, please read the following content carefully: The warranty period of our company's products is one year from the date of purchase or longer if local laws impose a longer minimum term, in which case the minimum term is the warranty period. During the warranty period, any faults caused by the product itself or for quality problems that arise under normal usage, LifeSmart will provide a free replacement.

User support e-mail address support@ilifesmart.com
Website



ATTENTION

The following conditions are not covered by the warranty:

- Product failure or damage caused by installation, use, and maintenance that is not in accordance with the product instructions;
- · Products beyond the warranty period;
- Products that have the barcode tampered with or removed;
- Devices that have been tampered with or customized outside of LifeSmart Terms Of Service as on the LifeSmart APP and website:
- User-caused damage, such as inappropriate voltage input, high temperature, accidental spillage, physical damage, etc;
- Product failure or damage caused by force majeure such as earthquakes, fires, or floods:
- Product failure or damage caused by other problems except the product itself.

DECLARATION

LifeSmart is a trademark of Hangzhou LifeSmart Technology Co., Ltd. As for the trademarks, product logos and product names from other companies presented within this manual, they are possessed by their own right holders. Without our written permission, no entity or individual shall extract, copy or disseminate in part or the whole of the manual contents in any form. Due to product version upgrades or other reasons, content of this manual may change. Our company reserves the right to change the contents of this manual without any notice. This manual is used only for instructional purposes. We strive to provide accurate information in this manual, but we are not able to ensure that the content of this manual is current. Statements, information and advice in this manual do not constitute any expressed or implied assurance. Updated manuals are available on our website at www.ilifesmart.com or by contacting our team.